

Samsung TVs | Easy | 2 min read

How to connect Bluetooth headphones to a Samsung TV

Please note: independent guidance. Vision Tech is not affiliated with the maker. Menus differ between models and software versions, so check the manual or on-screen help.

Bluetooth headphones are handy for late-night viewing, or if someone is hard of hearing. Many recent Samsung TVs can pair with them, although not all models do.

Check your TV supports it

Most TVs from the last several years have Bluetooth. If your TV does not offer Bluetooth audio, you will need a Bluetooth transmitter that plugs into the headphone or optical output. Check the e-Manual if unsure.

Pair your headphones

1. Put your headphones into pairing mode. This usually means holding the power button until a light flashes. Your headphone instructions will say how.
2. On the TV, press **Home** and go to **Settings**.
3. Go to **Sound > Sound Output** and look for **Bluetooth Speaker List** or a similar option.
4. Choose your headphones from the list and confirm.

Menu names can differ between models and years. If you cannot find it, search **Settings** for "Bluetooth".

Switching between headphones and speakers

When headphones are connected, the TV usually sends sound to them. Go back to **Sound Output** and choose **TV Speaker** to switch back. Some Samsung TVs can play sound through the speakers and headphones at once, but this depends on your model.

If they will not connect

- Make sure the headphones are charged.
- Keep them within a few metres, in line of sight.
- Remove old pairings on the headphones and TV and try again.
- Switch the headphones off from other devices such as your phone, as many remember only one device.
- Restart the TV.

Sound delay

Bluetooth can cause a small delay in sound. See our guide on sound out of sync.

Hearing aids

Some Samsung TVs support Bluetooth hearing aids. Look in the **Accessibility** area of **Settings** and check your model's manual.

When to get more help

If the TV never shows Bluetooth options, it may not support them. Vision Tech can help you choose a transmitter.

Still stuck? Email admin@visiontech336.com and tell us what you can see on the screen. Menus and button names can differ slightly between versions and makes. If something does not match, stop and ask rather than guess. Please never send passwords or card details.